

## Scope of Maintenance Service A & B : 保養服務 A 及 B 範圍:

Wheels, Brake 輪胎，制動系統	A	B
Check tyre condition 檢查輪胎狀態	•	•
Check wheels for damage 檢查車輪有否損壞	•	•
Check wheels for crack formation 檢查車輪有否裂紋	•	•
Correct tyre inflation pressure 校正輪胎氣壓	•	•
Test brake on test stand 制動測試台測試制動系統	•	•
Test parking brake on test stand 制動測試台測試手掣效能	•	•
Check thickness of front and rear brake pads 檢查前後制動皮厚度 (使用量度制動皮之特別工具)	•	•
Remove & install wheels for thickness check of front and rear brake discs 拆裝車輪檢查前後制動碟厚度	•	

Vehicle Underchassis 車身底盤	A	B
Check all visible parts for leaks 檢查主要配件有否泄漏情況		•
Check all visible parts for damage 檢查主要配件有否損壞		•
Check condition of flexible coupling 檢查傳動軸軸節狀況		•
Check play of front axle ball joints 檢查頭懸掛球窩接頭虛位		•
Check front axle rubber boots condition 檢查頭懸掛球窩接頭塵罩狀況		•
Check play of track rods 檢查轉向連杆		•
Check play of drag link linkage 檢查連杆球窩接頭虛位		•
Check track rods rubber boots condition 檢查轉向連杆接頭塵罩狀況		•
Check condition of suspension struts / shock absorbers and springs 檢查懸掛支柱 / 避震機及彈弓		•

Engine Compartment 引擎倉	A	B
Change engine oil and filter 更換機油及油隔	•	•
Check all visible parts for damage 檢查主要配件有否損壞		•
Check all visible parts for leaks 檢查主要配件有否泄漏情況		•
Check visible area of poly-V belt for wear 檢查皮帶有否磨損		•
Clean water drain in air duct (if applicable) 清潔風道的排水口 (如適用)		•
Clean water drain in water duct (if applicable) 清潔水道中的排水口 (如適用)		•
Check engine compartment air flap (if applicable) 檢查進氣喉風門片 (如適用)	•	•

Fluid Level 液體存量	A	B
Check engine coolant level 檢查引擎冷卻液液位		•
Fill in engine coolant level (if applicable, excluded parts) 補充引擎冷卻液 (如適用, 不包括零件)		•
Check brake fluid level 檢查制動系統油量	•	•
Fill in brake fluid (if applicable, excluded parts) 補充制動系統油 (如適用, 不包括零件)	•	•
Replace windshield washer system fluid 更換擋風玻璃清洗液	•	•
Check power steering fluid level 檢查動力輔助轉向系統油量		•
Fill in power steering fluid (if applicable, excluded parts) 補充動力輔助轉向系統油 (如適用, 不包括零件)		•
Check AdBlue level (applicable to diesel model only) 檢查尿素液位 (適用於柴油汽車)	•	•
Fill in AdBlue (if applicable, excluded parts) 補充尿素液 (如適用, 不包括零件)	•	•
Check active body control fluid level (applicable with this equipment) 檢查主動車身控制系統油量 (適用於有此配備)		•
Fill in active body control fluid (if applicable, excluded parts) 補充主動車身控制系統油 (如適用, 不包括零件)		•

Vehicle Front and Rear End 車頭及車尾部份	A	B
Check battery condition 檢查電池狀況	•	•
Check Starter battery condition (if applicable) 檢查撻車電池狀況 (如適用)	•	•
Check Backup battery condition (if applicable) 檢查輔助電池狀況 (如適用)	•	•
Check exterior lights for proper operation 檢查車外燈操作	•	•
Check wiper blades condition 檢查水撥片狀況		•
Check headlamp range adjustment system (excluding Xenon headlamp) 檢查頭燈高低調控系統操作 (不包括氙氣頭燈)		•
Check the adjustment of headlamps (if applicable) 檢查頭燈設定調節值 (如適用)		•
Correct the adjustment of headlamps (if applicable) 調較頭燈設定調節值 (如適用)		•

Trunk 行李箱	A	B
Check trunk lighting 檢查行李箱照明	•	•
Check expiry date of TIREFIT tire repair kit (if applicable) 檢查補胎液到日期 (如適用)	•	•
Check spare tire pressure (if applicable) 檢查後備輪胎氣壓 (如適用)	•	•
Correct spare tire pressure (if applicable) 調較後備輪胎氣壓 (如適用)	•	•
Check expiry date of first aid kit 檢查急救包到日期	•	•



## Mercedes-Benz Maintenance Service New Price List 平治星級保養服務全新定價

Regular maintenance is essential to keep your Mercedes in top condition and retain its value. With over 60 years experience, Zung Fu is your trusted partner to get your Mercedes-Benz serviced – we provide Service plan A and B which are specifically designed for your needs. Same day car return available\*.

定期保養對維持座駕的狀態及保障二手價格極為重要。擁有超過六十年的專業經驗，仁孚比任何人都更清楚您的平治。我們特別為不同需要設計保養服務計劃A和計劃B，更可即日\*完成，讓您安心取回座駕。

Enquiries/Book a Service 查詢及預約：2885 0138

\*with no repair work required  
如不需任何維修項目



## Mercedes-Benz Maintenance Service Price List : 平治保養服務價目表:

Model 型號	Maintenance Service A 保養服務 A (HK\$)	Maintenance Service B 保養服務 B (HK\$)
A-Class	1,988-2,188	3,280-3,680
B-Class	1,988-2,088	3,280-3,680
C-Class	2,088-2,688	3,480-4,180
CLA-Class	2,088-2,188	3,380-3,680
CLS-Class	2,588-2,688	3,880-4,080
E-Class	1,988-2,788	3,580-4,180
G-Class	2,688-2,788	4,380-5,280
GLA	1,988-2,188	3,380-3,680
GLB	1,988-2,088	3,680
GLC	2,288-2,688	3,780-4,180
GLE	2,388-2,688	4,080-4,680
GLS	2,388-2,688	4,080-4,380
EQC	2,088	2,780
ML-Class	2,288-2,788	4,580-5,080
S-Class	2,388-2,988	4,280-4,880
SL-Class	2,388-2,988	3,880-4,280
SLK-Class	2,088	4,380
SLC-Class	2,188-2,288	4,280-4,380
GT-Class	2,380-2,688	4,080-4,280
Viano V-Class	2,488-2,788	3,380-3,880
Smart	1,788-1,888	2,880-2,980

• In case of any dispute, Zung Fu Motors (Macau) Ltd. reserves the right of final decision.  
如有任何爭議，仁孚行有限公司保留最終決定權

• For more information, please call us at 2885 0138 or visit our service centre  
如有查詢，歡迎致電 2885 0138 或親臨平治汽車維修中心

• The above package price includes both labour and parts  
上述套餐已包括人工及零件

• Prices are subject to change without prior notice  
如有價錢更改，恕不另行通知

## Scope of Maintenance Service A & B : 保養服務 A 及 B 範圍:

Vehicle Interior (function test) 車廂內 (功能測試)	A	B
Check function of control units with Mercedes-Benz XENTRY Diagnostic 平治專用電腦診斷檢查	•	•
Delete fault memory with Mercedes-Benz XENTRY Diagnostic (if applicable) 平治專用電腦診斷儀清除故障編碼 (如適用)	•	•
Check horn 檢查警號	•	•
Check indicator lamps in instrument cluster 檢查指示燈	•	•
Check interior illumination 檢查內部照明	•	•
Check windshield wiper system 檢查擋風玻璃水擦系統	•	•
Check windshield washer system 檢查擋風玻璃清洗系統	•	•
Check headlamp cleaning system (if applicable) 檢查大燈清洗裝置 (如適用)	•	•
Reset service indicator in instrument cluster 重新設定儀錶板上的維修指示	•	•
Replace A/C combination / interior compartment dust filter (if applicable) 更換冷氣組合式過濾隔 / 車箱內塵隔 (如適用)	•	•
Replace A/C dust filter in engine compartment (if applicable) 更換引擎倉內冷氣塵隔 (如適用)	•	•
Check battery for KEYLESS-GO Key (if applicable, excluded parts) 檢查 KEYLESS-GO 鎖匙電池 (如適用, 不包括零件)	•	•
Replace battery for KEYLESS-GO Key (if applicable, excluded parts) 更換 KEYLESS-GO 鎖匙電池 (如適用, 不包括零件)	•	•
Check seat belts for external damages 檢查安全帶是否有損壞	•	•
Check seat belt buckles for external damages 檢查安全帶鎖扣是否有損壞	•	•
Check charging cable for mechanical damage (if applicable) 檢查充電線是否有損壞 (如適用)	•	•
Check charging socket for mechanical damage (if applicable) 檢查充電插是否有損壞 (如適用)	•	•
Check starter (if applicable) 檢查起動機 (如適用)	•	•
Clean seal on Vario roof (if applicable) 清潔軟蓬上的膠邊 (如適用)	•	•
Apply lubricant to seal on Vario roof (if applicable) 塗抹潤滑劑在軟蓬上的膠邊 (如適用)	•	•
Vario roof: Clean weather seal (if applicable) 清潔折疊式硬蓬上的膠邊 (如適用)	•	•
Vario roof: apply lubricant (if applicable) 塗抹潤滑劑在折疊式硬蓬上的膠邊 (如適用)	•	•

• The recommended maintenance interval is 1 year or every 12,000km whichever comes first.  
廠方建議最理想保養間距為一年或每12,000公里 (以先達者為準)

• The recommended maintenance interval of V-Class is 1 year or every 25,000km whichever comes first.  
廠方建議V系列最理想保養間距為一年或每25,000公里 (以先達者為準)



### Service Centre 維修中心

Edificio Industrial San Nam,  
R/C, Largo de Pac On Nos. 88-88D,  
Taipa, Macau  
澳門氹仔北安前地88-88D新南工業大廈地下

### Business Hours 營業時間

Monday - Friday 星期一至五 : 8am - 7pm  
Saturday 星期六 : 9am - 1pm 2pm - 6pm  
Sunday and Public Holiday : Close  
星期日及公眾假期 : 休息

Enquiries/Book a Service 查詢及預約 : 2885 0138  
Emergency hotline 緊急支援熱線 : 6591 1360



Follow our Facebook page now to receive more information.  
關注我們的Facebook專頁以獲取更多資訊!

www.zungfu.com.mo